

WHAT IS PLAYAWAY?

Playaway is the simplest way to listen to an audiobook on the go. With the audio already contained within, and a battery to make it play, there's nothing left to do but plug in earphones and enjoy.

As the first self-playing audiobook, Playaway brings pages to life at the push of a button. Audio content and simple, digital technology are now merged into an easy-to-use, self-contained player. And weighing only two ounces, Playaway is small enough to fit in the palm of your hand and goes anywhere you do!

A FUN NEW WAY TO EXPERIENCE AUDIOBOOKS!

In addition to our currently available collection of audiobook titles available on CD, Cassette, and online via NetLibrary in downloadable eAudiobook format, Hurst Public Library is proud to introduce our new Playaway audiobook collection. For more details or a list of available titles, ask about Playaways at the Adult Services Desk, or search our online catalog.

PLAYAWAY®

A HOW-TO GUIDE



HURST PUBLIC LIBRARY
901 Precinct Line Rd
Hurst, TX 76053
T:: 817.788.7300
www.hurst.lib.tx.us

For more information on Playaway,
visit www.playaway.com.



WHAT THEY ARE SAYING ABOUT PLAYAWAY


"The Best Inventions of the Year"
- *TIME Magazine*

"25 Products That Will Change Your Life"
- *Reader's Digest*

"Listen to this genius idea: self-playing audiobooks—smaller than a deck of cards—that come with earphones."
- *Oprah Magazine*



GETTING STARTED



STEP 1:
Plug a set of earphones, external speakers or a car adapter into the universal headphone jack.



STEP 2:
Press the Power button.






STEP 3:
Press the Playaway button and enjoy!



PLAYAWAY FUNCTIONALITY

- 1 EQUALIZER:**
Press to rotate to a new EQ mode
- 2 POWER:**
Press once to turn unit on
Hold down for 3 seconds to power off
- 3 SPEED:**
Press to change narrator speed
- 4 VOLUME DOWN:**
Press once to decrease one level
Hold down to accelerate decrease
- 5 LCD SCREEN:**
Displays operating status
Battery level indicator
- 6 VOLUME UP:**
Press once to increase one level
Hold down to accelerate increase



- 7 REVERSE:**
Press once to reverse by chapter
Hold down to reverse scan within chapter
- 8 PLAY/PAUSE:**
Press the  button to Play
When in play mode, press the  button again to Pause playing or resume Play
- 9 FORWARD:**
Press once to advance by chapter
Hold down to scan forward within chapter